

BETO Curve Direct R400mm 180°

Instructions for the lighting configuration of a BETO Curve

- 1 Use the provided photometric file
Attention: you only get the light emitting surface (cyan lines in drawing)
- 2 Create two boxes*, with 250mm
***blue lines in drawing**
- 3 Set the boxes and the photometric files as shown in the following drawing

